



PIN 1 and 2 of M2 need to be swapped.
Easiest is to install M2 upside down, with legs folded down to meet with PCB
M2 is only populated if SPI Port expander is installed.

D3, D4, D5 have an error on the PCB Silkscreen and should be mounted backwards